


Exterior






Front interior






Front interior

В Inside lock buttons P. 48 Driving position memory switches P.70 Seat position memory switches * P.75 Shoulder anchor control switches P. 81 Window lock switch P. 94 CLYPIAD148 Door lock switch P. 48 Power window switches P. 94




Instrument panel



Α

▶ Without touch screen



Rear window and outside rear view mirror defoggers P. 279

► With touch screen (without navigation system)



Rear window and outside rear view mirror defoggers P. 279

Audio system P. 305

► With touch screen (with navigation system)





Rear window and outside rear view mirror defoggers P. 279

- Audio system *1


^{*1:} Refer to "Navigation System Owner's Manual".

Instrument panel






Rear interior (5-seat models)








Rear interior (4-seat models)







Rear interior (4-seat models)

